StarLine E9 V2 Security – telematic system connection diagram



Mount the wiring far from sources of electrical interference: ignition coils, high-voltage wires, etc.

Make sure that the harness is not lay in contact with the moving parts of the vehicle: pedals, steering shaft etc.

Connect all the harness to the main unit sockets only after all wires mounting is complete.

Do no fit the engine temperature sensor near the exhaust manifold, otherwise it may cause sensor overheating and damage.

Only the qualified and trained fitter may carry out the security system installation.

The configured parameters of the security systems must comply with a vehicle manual instruction requirements.



can.starline.ru

StarLine E9 v2 Additional connection options Configuring the security-telematic system

Diagram of starting circuit connection on cars with Push-to-Start button

- 1. In Starline Master program configure the blue output wire of X2 connector as "Simulation of the brake or clutch pedal", and the black-yellow output wire of X2 connector - as "Engine start Start-Stop button"
- 2. Connect the wires according to the diagram



Eberspächer heater connection with digital bus control



Webasto heater connection with digital bus control



NOTE! The tags included in the delivery set are already registered in the main unit and are in the transport mode, i.e. off. Pressing the tag button in this mode will be indicated by a green and red flashes of the built-in LED. Prior to operation press the tag button several times until the LED color turn to green (regular mode).

New devices registration

NOTE! At registration of new tags and smartphones all previously registered tags and smartphones will be erased from memory. So the existing devices should be registered simultaneously in one cycle with all the new devices. In total up to 5 Bluetooth devices can be registered in the system main unit. When new RF remote keys are registered, all previously registered remote keys will be erased from memory. So the existing remote keys should be registered simultaneously in one cycle with all the new remote keys. In total, up to 4 RF remote keys can be registered in the system main unit.

Entry in the device registration mode

- 1. Disarm the security system.
- 2. Switch ignition Off if it is On.
- 3. Press the valet button 7 times.
- 4. Switch ignition On. 7 light LED flashes of service button and 7 buzzer sounds will follow.
- 5. 2 short LED flashes and buzzer sounds will confirm entry into the Registration mode.

Remote key registration

- Press a remote key buttons 1 and 2 shortly.
- 7. In 3 seconds successful registration will be confirmed by a short beep sound of a remote key, 2 LED flashes of a service button and 2 buzzer sound signals. If a remote key is not registered, 4 beep sounds of a remote key will follow. 8. Repeat points 6-7 for each remote key.

Bluetooth tags registration

- 9. Remove a battery from a tag.
- 10. Hold a tag button pressed and insert a battery back. A tag LED will turn red.
- 11. Release a button, a series of red flashes will follow.
- 12. In 10 seconds successful registration will be confirmed by a green LED flash, 2 flashes of a service button LED and 2 buzzer sounds. If a tag is not registered LED will turn red.
- 13. Repeat points 9-12 for all the remaining tags.

Smartphone registration

14. Register a smartphone* with use of the free StarLine mobile App.

Exit from the device registration mode

- 15. In 10 seconds switch ignition Off to exit the registration mode. An exit from Registration mode will be confirmed by double LED flashes and buzzer sounds and then additional signals in amount of total registered tags, keys and smartphones will follow.
- * The iOS and Android smartphone with Bluetooth Smart 4.2 and above are supported.

Programming an owner authorization code (with car buttons)

- 1. Disarm security system.
- 2. Switch ignition Off, if it is On, then press service button 7 times. 3. Switch ignition On.
- 4. 7 LED flashes of service button and 7 buzzer sounds will follow.
- 5. Then 2 LED flashes of service button and 2 buzzer sound signals will follow, confirming entry into Registration mode.
- 6. Enter the owner authorization code using car OEM buttons with a pressing interval no more than 3 seconds. Every button pressing should be followed by a single service button LED flash. The owner authorization code consists of a code sequence containing from 3 to 30 OEM buttons pressing. The list of supported OEM buttons is available at can.starline.ru. If a service button LED flash does not follow after pressing of OEM button, so this button is not supported for this car.
- 7. In 3 seconds after the code entry 2 short LED flashes and 2 buzzer sound will follow, confirming the code successful registration.
- 8. Enter the owner authorization code again.
- 9. If the code is recorded properly, 2 LED flashes and 2 short buzzer sound will confirm. If the code recording is failed, so 4 short buzzer sounds will follow, in this case repeat steps 6-8.
- 10. In 10 sec switch ignition Off to exit the Registration mode.
- 11. An exit from Registration mode will be confirmed by double LED flashes and buzzer sounds and then additional signals in amount of total registered tags, keys and smartphones will follow.
- 12. Write down and memorize this entered Authorization code.